

 STELLA 

Powered by
 **anubesport**[®]

MAIN SCREEN



NUMBER OF THE TARGET WAYPOINT

NAME OF THE TARGET WAYPOINT

CAP

TOTAL ODOMETER

The image shows the main screen of a Stella EVO device. The screen displays the following information:

- At the top: "STELLA III EVO" with a blue star icon.
- On the left: "95⁰" (Speed).
- On the right: "K27S" (Waypoint name) and "026" (Waypoint number).
- At the bottom right: "025.48" (Total Odometer).
- At the bottom left: "0000" (Small display).
- At the bottom center: Three buttons: a red button with a white exclamation mark (Warning), a green button with "OK", and a blue button with a white car icon and signal waves (Bluetooth).
- At the bottom right: "Powered by anubespport" logo.


WAYPOINT PROXIMITY



The image shows a Stella EVO display with the following information and callouts:

- STELLA EVO** logo at the top.
- Waypoint ID: **026 K27S**
- Distance to waypoint: **512** (Callout: **DISTANCE TO WAYPOINT**)
- Direction: **320°** (Callout: **TARGET WAYPOINT DIRECTION**)
- Total odometer: **026.82** (Callout: **TOTAL ODOMETER**)
- CAP** (Callout: **CAP**)
- Bottom bar with icons: a red warning triangle, a green **OK** button, and a blue car icon with a signal symbol.
- Powered by **anubespport** logo at the bottom right.

SPEED ZONE





SPEED
LIMIT

SPEED
LIMIT



REAL SPEED

REQUEST MEDICAL ATTENTION IMMEDIATELY





1 sec.



SOS




CAUTION VEHICLE STATIONARY



3 sec.
BREAKDOWN



DANGER 3 !!!



Notification 300m before an area marked in the roadbook as "Danger 3"

OVERTAKING / BLUE FLAG




FLASHING


OVERTAKE REQUEST



OVERTAKING / BLUE FLAG




STEADY




FLASHING



OVERTAKING / BLUE FLAG




FREE TO OVERTAKE





STEADY



PRESS THE BLUE BUTTON TO CONFIRM



SPEED LIMIT





SPEED LIMIT



SPEED LIMIT





RED STEADY Inside of speed zone
RED FLASHING Overspeed





SPEED LIMIT





OFF end of speed zone





NEUTRALIZATION ZONE





NEUTRALIZATION ZONE





NEUTRALIZATION ZONE





NEUTRALIZATION ZONE



NEUTRALIZATION ZONE



NEUTRALIZATION ZONE



MESSAGES



STELLA /// EVO

ARE YOU OK?

NO YES

0000

! OK 📞

Powered by anubespport



STELLA /// EVO

NEED DOCTOR?

NO YES

0000

! OK 📞

Powered by anubespport



STELLA /// EVO

WRONG WAY!

OK

0000

! OK 📞

Powered by anubespport



STELLA /// EVO

RESCUE IS COMING

OK

0000



! OK 📞

Powered by anubespport

WAYPOINTS LIST




OK



TOTAL ODOMETER RESET TO ZERO




OK




1 sec.

+



1 sec.

+



1 sec.

 STELLA 

Powered by
 **anubesport**[®]